


whitney

ADVENTURE: EXTENDED BACKPACKING

GROUND BREAKING TECHNOLOGY SINCE 1977

In 1977 Wayne Gregory started Gregory Mountain Products out of the back of a small outdoor equipment store in San Diego, California. This new company focused on quality, a custom fit and innovation, principles that are still strictly adhered to today, 28+ years later. Wayne continues to take an active role in the design of new packs as the head of research and development, directing a talented group of designers in developing the best fitting, most functional packs available.

Since then, Gregory has evolved into the most trusted name in backpacks. From the Appalachian Trail to the Rockies, Denali to the desert Southwest, you'll see Gregory packs. We continue to blend innovation, durability and passion. From week long excursions to spontaneous "shirt on your back" epics, our packs are designed with functionality and flexibility in mind. Whether your passion is hiking, biking, climbing, running, skiing or a mixed bag, we've got your back!



gregory

FIT

WAYNE GREGORY HAS SPENT 28+ YEARS DESIGNING BACKPACKS THAT FIT YOUR BODY. LIKE A GOOD PAIR OF SHOES, A PROPERLY FIT PACK WILL BE MORE THAN COMFORTABLE, IT WILL DISAPPEAR FROM YOUR MIND. THESE ARE SOME OF GREGORY'S EXCLUSIVE FIT FEATURES:

- Adjust•A•Cant[™] Waistbelt : Adjusts the waist belts' angle and transfers the weight to the hips where it is most comfortably carried.
- Auto Cant™ Harness System : Adjusts the shoulder harness angle to eliminate chafing and pinching on the shoulders and neck.
- Flo•Form[®] II : Our special combination of durable foams, flame lamination, and molding provide incredible comfort and long-term durability. Used for harnesses and waist belts.
- Multiple Frame, Shoulder Harness, and Waistbelt Sizes : No two body shapes are the same. We offer a variety of frame and component sizes to custom fit each pack to your unique shape.

QUALIITY

THE PACK YOU ARE HOLDING IS CONSTRUCTED WITH THE ABSOLUTE HIGHEST QUALITY STANDARDS POSSIBLE. AT EVERY STAGE OF THE DESIGN AND MANU-FACTURING PROCESS, GREGORY PACKS ARE CONSTRUCTED WITH THE HIGHEST QUALITY MATERIALS.

- Highest Quality Materials : Many manufactures cut costs by compromising the quality of the materials they use in creating their product. Gregory packs utilize the highest quality materials in all aspects of the pack, from the pack cloth itself to the shatter-proof YKK buckles.
- Lifetime Guarantee : We build Gregory products to last a lifetime and that is how long we stand behind them. We guarantee to you, the original purchaser, that this product will be free from defects in materials or workmanship as long as you own it.

selection

HOW TO SELECT

You will need to determine the following when selecting a pack:

1. What volume or capacity pack do I need?

Ask yourself: On average, how many days will I be living out of my pack? Will I be traveling primarily in the summer, or the winter? Am I a light, medium, or heavy packer? Use this chart as a guide or bring your gear to the store to see how it fits.

COMFORT RANGE	FULL-BLOWN EXPEDITIONS	EXTENDED Backpacking	WEEKEND WARRIORS	WEEKEND LIGHT & FAST	MULTI-SPORT DAY USE
	65 lbs.or more	Upto 65 lbs.	Upto 45 lbs.	Up to 35 lbs.	25 lbs.or less
	DENALI™ PRO PETIT DRU™PRO*	WHITNEY™ LASSEN™	MAKALU™PRO BALTORO™	Z™ РАСК G™РАСК	ADVENT™PRO ARREBA™*
RIGHT FOR ME?		PALISADE® SHASTA™ ELECTRA™*	TRICONI™ WINGATE™ PINGORA™ DEVA™60* MAVEN™*	TEGA™* IRIS™* ALPINISTO™ 55 ZULU™	ISO™ REACTOR™ STIMULUS™ EKKO™ HALO™ ADZE™
WHICH PACK IS F					JUXT™ KYRO™ NANO™ SPECTRUM™

*DENOTES WOMENS SERIES PACKS

2. What frame and component sizes do I need?

Ask yourself: What is my torso length? What is my frame size? What are my waistbelt and shoulder harness sizes? (Fitting information starts on page 6.)

whitney™

WHY BUY THIS PACK?

The most fully featured pack in the Adventure Series, the Whitney caters to those seeking backcountry organization: 4 access points, a plethora of pocketry options and the best heavy load carrying suspension in the business.

FIT

- AUTO CANT™ : ADJUSTS HARNESS ANGLE TO ELIMINATE PINCHING AND CHAFING
- ADJUST•A•CANT™ : ADJUSTS THE WAIST BELT ANGLE AND TRANSFERS WEIGHT
- FLO·FORM® II HARNESS : SEAMLESS, WRINKLE FREE COMFORT AND DURABILITY
- FLO-FORM® II WAISTBELT : CUPPED, SEAM-LESS, WRINKLE FREE COMFORT
- CHIMNEY VENTED BACK : CIRCULATES AIR TO KEEP YOU COOL

PACK

- TOP, FRONT, SIDE, AND BOTTOM ACCESS : EASY AND QUICK TO REACH ALL YOUR GEAR
- BARN DOOR SIDE POCKETS : STORAGE, ORGANIZATION, AND ACCESS
- FRONT POCKET : STORAGE, ORGANIZATION, AND ACCESS
- CANTED WATER BOTTLE HOLSTER : EASILY ACCESS YOUR WATER WHILE HIKING
- TOP POCKET : CONVERTS TO A WAIST PACK
- HYDRATION SLEEVE AND PORT : FITS MOST RESERVOIRS AND BITE VALVES
- WATER RESISTANT TOP POCKET ZIPPER : HORSESHOE SHAPED FOR EASY ACCESS TO THE POCKET'S CONTENTS




MATERIALS

- 210D "DOUBLE BOX" HT NYLON BODY FABRIC: LIGHTWEIGHT AND DURABLE
- SHELTER·RITE® BOTTOM : EXTREMELY DURABLE AND WATERPROOF
- TWO 7001-T6 STAYS : STIFF YET TORSIONALLY FLEXIBLE TO SUPPORT THE LOAD
- FLOATING FRAMESHEET : PARTIAL FRAMESHEET IS SUPPORTIVE YET TORSIONALLY FLEXIBLE

GREGORY ACTIVE SUSPENSION

terms


To identify suspension parts mentioned on the following pages, please familiarize yourself with these general terms.



DOES YOUR PACK FIT RIGHT?

Follow these steps (in numerical order) for a perfect custom pack fit:

quick fit



HAVING THE PROPER FIT IS EXTREMELY IMPORTANT TO US!


In order to enjoy the comfort and performance that has made Gregory the leader in overnight packs, it is absolutely critical that your pack meets the fit criteria shown here. If you have any questions regarding fit, contact your authorized Gregory dealer, e-mail us at customerservice@gregorypacks.com, check out our web site at www.gregorypacks.com, or call us at: 800-477-3420. We're here to help!

HOW TO CUSTOM FIT A PACK TO YOUR BODY

FRAME SIZE

Measure your torso length using a flexible tape measure, or Gregory Fit-O-Matic[™]. Do it two or three times, just to be sure.


IF YOUR TORSO MEASUREMENT		YOUR FRAME SIZE SHOULD	BE:
14" - 15 ¹ /2"	/ 35-39cm	x	5
16"-17 ¹ /2"	/ 40-44cm	SI	m
18" - 19 ¹ /2"	/ 45-49cm	m	d
20" - 21 ¹ /2"	/ 50-54cm	Ig	ł




fit

WAISTBELT SIZE

Measure your waist around the top of your hip bones.





WAISTBELT INSTALLATION

The Adjust A-Cant[™] panel is a critical fit feature. By adjusting the waist belts angle to mirror your hip shape you will be able to support the weight over a larger surface area for a more comfortable experience.

fit

Put the pack on with 10-15 pounds of weight and buckle the waist belt.

Lift your leg so your thigh is horizontal to the ground. The bottom edge of the waist belt should be level with the break in your leg (see the quick fit illustration on page 5).

Use your fingers to check for gaps at the top edge and lower edge of the waist belt.

If any gaps exist, remove the pack and waist belt (see page 6, Waistbelt size, for instructions on removing the waistbelt).

Use a coin or screwdriver to remove the brass bolts in the middle of the Adjust-A-Cant™ panel.

Angle the panel up or down and replace the brass bolts and waist belt pad.

Re-check for gaps, and adjust again if necessary.

Adjust A.Cant™ panel

SHOULDER HARNESS SELECTION

Shoulder harnesses come in six sizes:


- Men's: SM, MD, and LG - Women's: XS. SM. and MD

In general, the shoulder harness size is usually the same as the frame size. Check to make sure the main curve on the harness is level with your armpit. When sizing, make sure the load lifter straps on top of the harness are loose.



SHOULDER HARNESS INSTALLATION

The shoulder harness setting is determined by your torso length.





fit

Auto • Cant[™] Shoulder Harness Setting

Twist the metal slider at the top of the harness to remove it from the Auto Cant[™] slot. Reverse the process to re-install.

STERNUM STRAP ADJUSTMENT

The sternum strap may be moved up or down on the shoulder harness. The only rule of thumb is that it should be in a comfortable position, and it should not restrict your breathing.

POSITION ON YOUR BODY

With a lightly loaded pack on (15 to 20 pounds), the top edge of the waistbelt should ride about 1" above the top of your hip bones. Try lifting your leg so that your thigh is horizontal with the ground. The break in your leg should be level with the bottom edge of the waistbelt. If you push up on the waistbelt when you lift your leg, re-position the pack higher on your hips. (see fit illustration on page 6)

adjust

PUTTING ON YOUR PACK

Loosen the shoulder stabilizer, waistbelt stabilizer, and shoulder harness adjustment straps. Use your legs to lift the pack onto your body. Tighten your shoulder strap adjustment straps first. Shrug your shoulders skyward and attach the waistbelt – make sure the top edge of the waistbelt is 1" above the top of your hips. Now tighten the waistbelt and check to make sure your leg breaks at the bottom of the waistbelt pad. Lightly tension the shoulder stabilizer straps and check to see that they are at a 25 degree angle.

DISTRIBUTING YOUR PACKS WEIGHT

With a few quick adjustments you can shift the weight entirely onto your hips, or entirely onto your shoulders – or distribute it between the two. This allows you to relax or stress different parts of your body while in motion. Experiment on the trail to find the optimum adjustment for various terrains and activities.

SHIFTING THE WEIGHT FROM YOUR SHOULDERS TO YOUR HIPS

This is generally the most comfortable place to carry the weight, but experiment to find the weight distribution most comfortable for you.

- 1. Loosen the shoulder stabilizer straps and shoulder harness adjustment straps until you feel the weight of the load shift downward onto your hips.
- Tighten the shoulder stabilizer straps until there is about a finger's width of space (a gap) between the top of your shoulders and the shoulder harness.
- 3. Re-tighten the shoulder harness adjustment straps. You may want to tighten the waistbelt slightly in response to the weight transfer.

SHIFTING THE WEIGHT FROM YOUR HIPS TO YOUR SHOULDERS

Selecting a balance between your shoulders and hips will keep the pack stable for maximum balance and mobility:

- 1. Loosen the shoulder stabilizer straps by pushing up on the buckles.
- 2. Tighten the shoulder harness adjustment straps.
- 3. Lightly tension the shoulder stabilizer straps to stabilize the top of the pack. You may wish to loosen the waistbelt for additional weight transfer to the shoulders.

PACKING YOUR PACK

pack

A correctly loaded pack will not only be more comfortable, it will be better balanced for stream crossings, skiing, climbing, or on uneven terrain.

Start by loosening all of the packs' compression straps, and if you prefer, internal dividers. Put your sleeping bag in the bottom, we suggest using a compression stuff sack. Place your folded tent and rain fly on top of your sleeping bag.

Your heaviest items - food, fuel, water - should come next, and be placed close to your back, and no higher than your shoulders. Above these heavier items, and in the space away from your back, should be your lighter items, like clothes.

Side pockets should be used for fuel bottles, water bottles, or items you need to quickly access.

Once everything is loaded into your pack, cinch down the compression straps to stabilize the load and to pull it in close to your back.



CARING FOR YOUR PACK

care

Hand wash with a mild detergent or soap solution. Stubborn stains may require scrubbing with a soft-bristle nylon brush. Solvents may damage the pack's components and the fabric's waterproof coating. Rinse and air-dry with all zippers open. It is critical that you thoroughly dry your pack and store it in a dry place. Do not put your pack in the dryer as the heat may damage the fabric coating. Use of solvents or improper drying will void the warranty.

THE GREGORY LIMITED LIFETIME WARRANTY

We build Gregory gear to last a lifetime and that's how long we stand behind it. We guarantee to you, the original purchaser, that this product will be free from defects in materials or workmanship, for as long as you own it. If you think this product has any defects in materials, send it to us postpaid and clean with your proof of purchase. If the product is defective, then we will fix it or replace it with a new one and return it to you at our expense. For authorized repairs, call to get a return authorization number (RMA#), then send the product to us postage paid at: 27969 Jefferson Ave., Attn: Returns Department, Temecula, CA 92590.

This warranty does not cover damage due to unreasonable use or improper care (Sorry, no free repairs if you have been using your pack as a feed bag for bears or cleaning with white gas!). Here's the legal stuff: This is a limited warranty. The manufacturer shall not be held responsible for incidental or consequential damage nor the natural breakdown of materials which occurs with extended use. Some states do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

NON-WARRANTY REPAIR POLICY

If your Gregory pack or accessory needs repair due to normal wear and tear, accident, improper care or other causes, or if your pack is not under warranty, or you are not the original purchaser, we will provide repairs at a reasonable charge, plus shipping and handling. Please clean your pack, and then send it postage paid, and we will repair it after your approval and payment of our quote.

WARRANTY REGISTRATION

Thank you for purchasing a Gregory pack and welcome to our family! To register your pack for warranty go to our online registration page at: www.gregorypacks.com/warrantyreg.htm



1 800 477 3420 www.gregorypacks.com

whitney™

The most fully featured pack in the Adventure Series, the Whitney caters to those seeking backcountry organization: 4 access points, a plethora of pocketry options and the best heavy load carrying suspension in the business.



UPC

690565